

# SUPERDECK®

## Exterior Wood Brightener

# 1450



### General Description

**SUPERDECK® WOOD BRIGHTENER** is a concentrated product formulated to remove the dark brown to black discoloration from wood caused by tannin stains, nail stains, and rust stains. Wood Brightener should follow use of Superdeck® Wood Cleaner or Superdeck® Wood Stripper to bring back the natural color of the wood. Wood Brightener is also designed for use on new wood to safely remove mill glaze without causing damage.

### Recommended Substrates

For all exterior wood.

### Tinting & Base Color Information

Ready to use. Do not tint.

DB 1450

### Features / Benefits

- Removes Tannin & Rust Stains
- Removes Mill Glaze
- Concentrated Formula
- 1 Gal of Cleaner Makes 4 Gal of Cleaning Solution

### Product Application

#### **APPLICATION:**

Shake well before using. Wood Brightener is supplied as a concentrate. Mix 1 gallon of Wood Brightener to 3 gallons of water for normal use. Spray wood with water, then apply Brightener with a brush, roller or pump up sprayer. Use synthetic brushes or rollers only. Wood Brightener's thick formula may be used undiluted for difficult areas or vertical surfaces. For maximum effectiveness, keep Brightener wet on surface by occasionally misting with water. Allow

### Product Application (cont.)

15–30 minutes to restore natural color to wood. Wood Brightener becomes extremely slippery once applied. Work on small enough areas to avoid walking on treated surface.

#### **RINSING:**

Test a small area by scrubbing with a bristle brush to determine if the surface is ready for rinsing. When ready, scrub the surface with a firm bristle brush or long handled push broom. Rinse thoroughly with Water using a garden hose or pressure washer. Do not exceed 1000 PSI when using a pressure washer. Rinse any residue from plants.

#### **PRECAUTIONS:**

Apply product at temperatures above 50°F. and below 90°F. Do not apply in direct sunlight if possible. Protect any aluminum surfaces (such as window frames) to prevent discoloration. Product will etch metal. If product makes contact with glass, rinse thoroughly before it dries. Mist any nearby vegetation with water before and after application.

#### **COVERAGE:**

100–200 sq. ft. per gallon and will vary depending on the dilution of Wood Brightener to water.

#### **CLEAN UP:**

Clean all tools with water.

#### **SAFE USE & STORAGE:**

When using, do not eat, drink or smoke. Wash hands after use and before eating, drinking or smoking. Product is corrosive, avoid contact with metals such as aluminum. Do not transfer contents into a metal container or unlabeled container. Store in a well ventilated area. Keep container tightly closed when not in use. Protect from freezing. For exterior use only.



## Physical Properties

### DB1450 Exterior Wood Brightener

CAS Number    Ingredient

7732-18-5        Water

6153-56-6        Oxalic Acid

NON-PHOTOCHEMICALLY REACTIVE

VOC: 0 g/L – 0.00 lb/gal as per 40 CFR 59.406

## Cautions

**CAUTIONS:** Use only with adequate ventilation. To avoid overexposure, open windows and doors or use other means to ensure fresh air entry during application and drying. If you experience eye watering, headaches, or dizziness, increase fresh air, or wear respiratory protection (NIOSH approved) or leave the area. Avoid contact with eyes and skin. Wash hands after using. Keep container closed when not in use. Do not transfer contents to other containers for storage.

**FIRST AID:** In case of eye contact, flush thoroughly with large amounts of water. Get medical attention if irritation persists. If swallowed, call Poison Control Center, hospital emergency room, or physician immediately. **DO NOT TAKE INTERNALLY. KEEP OUT OF THE REACH OF CHILDREN.**

03/10 (230)

## Packaging

1-Gallon Container - 124 fl oz (3<sup>7</sup>/<sub>8</sub> U.S. Qt) 3.66 L

## Product Guarantee

**LIMITED WARRANTY:** If this product, when applied according to label instructions to a properly prepared surface, fails to perform in accordance with applicable product literature, Duckback Products shall, upon presentation of proof of purchase to Duckback Products or its authorized representative, either replace an equivalent quantity of product free of charge or refund the original purchase price. This warranty shall not apply to any defect or damage resulting from improper surface preparation, structural defects, or failure of a previous product. This is your sole remedy under this warranty. To obtain performance under this warranty, contact Duckback Products at (800) 825-5382 or [superdeck.com](http://superdeck.com). You may be asked to contact the retailer from whom you purchased this product for further warranty instructions. THIS WARRANTY EXCLUDES (1) LABOR OR COSTS ASSOCIATED WITH LABOR FOR THE APPLICATION OR REMOVAL OF ANY PRODUCT, AND (2) ANY INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may have other rights, which vary from state to state.